

PRINT/CHANNEL

*Emulate a 3211-type channel
printer*

*Documentation Edition 8
Software Version 9902 or later*

Editors

Becky Mooring
Michele Nylander
Diane Pedersen
Jennifer Saam
Seroj Terian

Hardware

Ken Clark



Copyright © 1992-1999 by Barr Systems, Inc.
All Rights Reserved.

Barr Systems, Inc.

4500 NW 27 Avenue
Gainesville, FL 32606-7031

Phone: 800-BARR-SYS
800-227-7797
352-491-3100

Fax: 352-491-3141

Internet: support@barrsys.com

Web site: www.barrsys.com

FTP site: [ftp.barrsys.com](ftp://ftp.barrsys.com)

The Barr logo is a registered trademark and BARR/CHANNEL adapter, BARR/PRINT for LAT, BARR/PRINT for TCP/IP, BARR/SPOOL, Channel Attach Box, CHANNEL-IN PCI adapter, PRINT370, and PRINT/TWINAX are trademarks of Barr Systems, Inc. LAT and VAX/VMS are trademarks of Digital Equipment Corporation. AS/400 and IBM are registered trademarks of International Business Machines Corp. MS-DOS is a registered trademark of Microsoft Corporation. UNIX is a registered trademark of The Open Group.

August 5, 1999



Preface

PRINT/CHANNEL emulates a 3211-type channel printer and allows you to route mainframe print jobs to network printers and share mainframe printers with network users (with the PRINT370 option).

Follow the instructions in this manual to install the PRINT/CHANNEL software.

Barr Technical Support

Contact Barr Technical Support at 800-BARR-SYS Monday through Friday between 9 a.m. and 8 p.m. Eastern time if you have questions or problems with Barr software or hardware. Technical Support will ask for your software version number and adapter serial number. When you call, please have this information on hand. If you contact Technical Support by fax, e-mail, or the web site support page, please include these numbers in your correspondence.

You can obtain the software version number from the following places:

- Second screen of the Installation menu
- Console portion of the Operation screen at software startup
- Quit screen during software operation

See your *BARR/CHANNEL* or *CHANNEL-IN (BT)* hardware manual for adapter serial number locations.

Notes:



Contents

Preface	iii
Chapter 1 Introduction	1
1.1 Features	2
1.2 Requirements	5
1.3 Host Configuration	5
1.4 Package Contents	6
Chapter 2 Configure the PRINT/CHANNEL Software (ISA Adapter)	7
2.1 Define Print Sessions and Addresses	8
2.2 Define the Adapter	17
2.3 Assign Devices	20
Chapter 3 Configure the PRINT/CHANNEL Software (PCI Adapter)	33
3.1 Define Print Sessions and Addresses	34
3.2 Define the Adapter	42
3.3 Assign Devices	45
Chapter 4 Run Diagnostics	57
4.1 Phase 1: Adapter Installation and Settings	58
4.2 Phase 2: CAB Installation and Connections	60
Chapter 5 Start PRINT/CHANNEL	63
5.1 Start from the DOS Prompt	63
5.2 Start from the Installation Description Menu	63
Appendix A Banner Page Detection Example	65

Appendix B Communication Scope and Console Messages	69
Warranty	71
Glossary	77
Index	79

Introduction

PRINT/CHANNEL allows you to route mainframe print jobs to network printers and share your mainframe printer with the network (with the PRINT370 option).

You can order PRINT/CHANNEL as an option with the BARR/SPOOL base product. With PRINT/CHANNEL and BARR/SPOOL, the Barr PC can emulate up to eight 3211-type channel printers with complete spooling features (see Figure 1-1).




Figure 1-1. PRINT/CHANNEL with BARR/SPOOL and PRINT370 allows you to share mainframe printers with the network.

You can direct mainframe print jobs to the spooler or to existing network print queues on a local area network (LAN). If you add the Barr PRINT370 option, you can also share mainframe channel printers with the rest of your network.

Depending on the other Barr product options you install, PRINT/CHANNEL also allows VAX, UNIX, and AS/400 hosts to share the mainframe channel printers (with the PRINT370 option) and network printers as shown in Figure 1-2.




Figure 1-2. PRINT/CHANNEL with BARR/SPOOL, PRINT370, and TCP/IP.

1.1 Features

PRINT/CHANNEL supports routing mainframe print jobs to your network printers and sharing your mainframe printer with other network users (with the PRINT370 option) via the features described in this section.

Multiple Printers

PRINT/CHANNEL provides up to eight printer sources you can route to any combination of parallel, serial, channel-attached, and network printers, depending on which Barr software options you include. The printer addresses do not need to be sequential, if the PCI adapter is used.

Spool Support

PRINT/CHANNEL with the BARR/SPOOL base product allows you to spool print files to a channel printer (with the PRINT370 option) or to network printers. Spooler features include restart, file view, and text search.

Convenient Channel Attachment

When you connect a PC to the mainframe, you need the ability to isolate the mainframe from the PC environment. The Barr Channel Attach Box (CAB) allows you to disconnect the PC without affecting the mainframe or other channel devices.

The CAB electronically isolates the channel signals from the PC. When you exit the software, the CAB disables the PC connection. LED indicators on the box show the status of the connection so you can tell if the host is operational, the Barr software is enabled, and communication is taking place.

Note: Always try to exit the PRINT/CHANNEL software normally before you power off or reset the PC. If you cannot do this, disable or power off the CAB before you power off or reset the PC.

Job Separation

The PRINT/CHANNEL input data stream is record oriented. The emulated IBM 3211 protocol does not provide an obvious mechanism to separate print jobs. You have to divide jobs in hard copy printouts by using banner pages as the breaks between jobs. PRINT/CHANNEL provides the following mechanisms to break the data stream into discrete print jobs:

- Banner recognition
- Forms Control Buffer (FCB) detection
- Timeout

Banner Recognition

The first, and perhaps most useful, job separation mechanism is by banner recognition. To use this feature, you must configure the program to recognize banner pages from the host (see the **Job separation by banner page recognition** option in Chapter 2 and a banner page detection example in Appendix A). You can use header, trailer, or both types of banner pages. During configuration, you specify a range of lines and one or two text strings. PRINT/CHANNEL looks for these strings on specified banner page lines at specified columns. After the program finds a banner page, that page becomes either the first (header) or last (trailer) page of the print job.

Ideally, you should configure PRINT/CHANNEL to recognize both headers and trailers. Depending on the layout of your particular banner pages, this might not be possible. If you configure a PRINT/CHANNEL printer to recognize headers only, the software has to cache each page until it determines if the page is a banner page. If you must configure your printer to recognize headers only, try to limit the search region to the top of the page if possible. If you tell the program that the banner-identifying text is somewhere between line 1 and line 60, then for each page of the job that is *not* a banner page (that is, most pages), the program must cache 60 lines before it can determine if the page belongs with the current job. If your pages are dense, this caching might have a noticeable impact on throughput.

FCB Detection

In the second mechanism, the program automatically breaks a job when it receives an FCB (primarily to include the FCB with the job that follows it in the data stream).

Timeout

The third mechanism is by timeout. By default, if the program receives no data from the host for 30 seconds, it closes the current job. If you use only header banner pages to separate jobs, PRINT/CHANNEL can determine only where a job begins, not where it ends. In this case, the program uses the timeout mechanism to close the job with no following job. (See the **EOF timeout in seconds** option in Chapter 2.)

Job Parameter Extraction

If you use header banner pages, you can configure PRINT/CHANNEL to extract useful parameters from the header page such as **Jobname**, **Formname**, **FCBname**, **Copies**, **Priority**, and **Class**. You specify the location of these parameters on the banner page relative to the line on which the program finds banner-matching text. You also specify the line on which the program should find each parameter as zero or more lines **BEFORE** or **AFTER** the banner text matching line. Zero lines **BEFORE** (or **AFTER**) refers to the line containing the matching text. See Chapter 2 for more information about parameter information. See Appendix A for a banner page example.

Optional S/390 Channel-Attached Printer Support

Barr's PRINT370 option can drive System/390 channel-attached printers at their maximum speeds. With this option, you install a PRINT370 adapter that emulates the channel in the PC. You can then attach up to six S/390 channel-attached printers to the adapter with bus and tag cables.

For a list of supported channel printers, see the Barr *PRINT370* manual.

Other Barr Options

Depending on memory availability, you can add these Barr software options to print to and receive print jobs from these hosts:

Options	Host
BARR/PRINT for LAT	VAX
BARR/PRINT for TCP/IP	UNIX
PRINT/TWINAX	AS/400

1.2 Requirements

You need the following hardware and software to run PRINT/CHANNEL:

- PC with at least 640 kilobytes (KB) of memory (varies according to the number of PRINT/CHANNEL printer sessions you define and the product/options you include)
- DOS 5.0 or later version
- BARR/SPOOL
- CAB
- CHANNEL-IN adapter

1.3 Host Configuration

PRINT/CHANNEL emulates a 3211-type channel printer. You must ask your host programmer to configure the mainframe to recognize and communicate with the PRINT/CHANNEL device.

1.4 Package Contents

PRINT/CHANNEL software, which is packaged with BARR/SPOOL, is included on this disk:



BARR/SPOOL software disk
with the PRINT/CHANNEL option

The *BARR/CHANNEL* or *CHANNEL-IN (BT)* hardware manuals list the hardware package contents.


Configure the PRINT/CHANNEL Software (ISA Adapter)

The Installation chapter in your *BARR/SPOOL* manual describes how to configure software from the Installation Description menu. This chapter discusses additional PRINT/CHANNEL options you need to specify and includes sample BARR/SPOOL and PRINT370 screens.

To run the Barr software, type the Barr software startup command followed by the letter **i** at the DOS prompt. For example, type the following:

```
spool i
```

The Installation Description menu displays.



- To configure the PRINT/CHANNEL settings, select **PRINT/CHANNEL Description**

2.1 Define Print Sessions and Addresses

You define the number of print sessions and first printer address on the PRINT/CHANNEL Description screen.

Description Options

PRINT/CHANNEL Description

Mainframe print sessions: 8
First printer address: 0E

Enter number

Mainframe print sessions:

Enter 1 to 8 printers. This is the number of channel printers you want the Barr software to emulate. This manual shows eight printer sessions.

First printer address:

Enter the first printer address in hexadecimal. The default is 0 E. If you define more than one printer, PRINT/CHANNEL numbers the printer addresses sequentially beginning with the first address. For example, if you define three printers and set the first printer address to 0 E, the printer addresses for the three printers will be 0 E, 0 F, and 1 0.

Note: Check with your host programmer for a range of available addresses. After you select the first address, PRINT/CHANNEL assigns the rest sequentially and you cannot manually override the range.

Print Session Options

1. Press **Enter** to display a list of all printers.

PRINT/CHANNEL Print Sessions		
Address	Name	State
<u>0E</u>	<u>CHOE</u>	<u>Enabled</u>
0F	CHOF	Enabled
10	CH10	Enabled
11	CH11	Enabled
12	CH12	Enabled
13	CH13	Enabled
14	CH14	Enabled
15	CH15	Enabled
Escape		
Adapter Description		

2. To define a printer, select it from the list.

Printer Definition Options

The PRINT/CHANNEL Printer Definition screen displays.

PRINT/CHANNEL Printer Definition	
Printer address:	<u>0E</u>
Enable or Disable device?	<u>Enabled</u>
EOF timeout in seconds (0 for none):	<u>30</u>
Intervention timeout in seconds:	<u>10</u>
Enforce UCS Size? <u>No</u>	UCS Size: <u>512</u>
Suspend EOF timeout after FCB? <u>No</u>	
Disable file separation by FCB? <u>No</u>	
Default lines per page:	<u>66</u>
Job separation by banner page recognition? <u>Yes</u>	
Choice? + -	

Printer address:

The printer address in hexadecimal. Each printer must have a unique address. This address must match the subchannel address at the host. If you installed an ISA adapter, you cannot change this field.

Enable or Disable device?

You can enable or disable the device to control its use.

Enabled Default. The device is online.

Disabled The device is offline.

EOF timeout in seconds (0 for none):

If the software receives no print data from the host for the specified length of time, it assumes the current print job is complete. The default is 30 seconds.

Intervention timeout in seconds:

This flow control tuning option can help reduce or eliminate unnecessary intervention messages on the host console. PRINT/CHANNEL might need to temporarily stop receiving data from the host. For example, if a PRINT/CHANNEL printer is directly connected to an output device and that device enters an intervention state, the data flow from the host must be suspended. It also might be necessary to stop receiving data while the program searches a large spool retain directory. While the program builds the retain file list, it suspends normal data flow.

When PRINT/CHANNEL detects the need to temporarily suspend data reception, it withholds sending a device end (DE) acknowledgment to the host. This normal action does not cause problems if DE is not withheld for too long.

You can configure the time limit on the host. Typically you would specify from 30 seconds to a few minutes. The PRINT/CHANNEL configuration option, **Intervention timeout in seconds**, tells the program how long to withhold DE from the host. The default value is **10** seconds. Then the program supplies the DE to the host (thereby avoiding a missing DE interrupt) and enters the Not Ready

state. The program rejects the next command from the host with an Intervention Required (not ready) sense. When the reason for suspending data flow is resolved, PRINT/CHANNEL enters the ready state and supplies a DE to the host. Normal data flow resumes.

If you receive **intervention required** messages (on the host console and the BARR/SPOOL Operations screen) and the messages are considered normal for your situation, you might be able to eliminate the messages by increasing the **Intervention timeout in seconds** value. Changing this value is merely cosmetic and will neither increase nor decrease your data throughput. Your mainframe operator might ignore these messages anyway knowing that you are already taking care of the problem.

Enforce UCS Size?

Specify whether the received Universal Character Set (UCS) is limited to a specific size.

- No** Default. PRINT/CHANNEL can receive any size UCS from the host.
- Yes** PRINT/CHANNEL can only receive up to the value set for UCS size. The UCS maps EBCDIC characters to print-chain positions. Because the PRINT/CHANNEL emulation does not contain a physical print chain, the program ignores the information contained in this command. Some host configurations detect an error unless the printer device accepts only a specified length UCS. By default, this length is 512 bytes. If your host requires this behavior, you should enable the **Enforce UCS Size** option and enter the actual size of the UCS your host sends.

UCS Size:

Specify the UCS size PRINT/CHANNEL can receive. The default is **512**. This option applies only if you set **Enforce UCS Size** to **Yes**.

Suspend EOF timeout after FCB?

You can use this option to temporarily suspend EOF timeout processing after PRINT/CHANNEL receives an FCB.

No Default. EOF timeout processing is not affected by receiving an FCB.

Yes PRINT/CHANNEL temporarily suspends the EOF timeout operation after it receives an FCB from the host. Normal EOF timeout processing resumes when PRINT/CHANNEL detects the end of the current page.

Disable file separation by FCB?

Specify whether files are to be separated by FCB.

No Default. Files are separated whenever an FCB is received.

Yes Files are not separated when an FCB is received.

Default lines per page:

Specify the number of lines per page to be used in the absence of an FCB. The default is 66 lines per page. If an FCB is received, the FCB values will determine the lines per page, overriding this setting.

Job separation by banner page recognition?

Specify whether to perform print job separation by banner recognition.

Yes Default. The program performs print job separation by recognizing host banner pages.

No Disable banner page recognition. You can only separate print jobs by timeout or a received FCB.

Copy PRINT/CHANNEL copies the banner recognition and spool parameter extraction information from the previous printer definition. This option only applies if you define more than one printer.

If you select **Yes** or **Copy**, the PRINT/CHANNEL Printer Definition screen displays again with banner recognition information.

Banner Recognition Options

```
PRINT/CHANNEL Printer Definition

Printer address:      0E
Enable or Disable device? Enabled
.....
Banner Recognition Information

Remove banner pages after processing? No

Starting line:  0      Number of lines:  1
Header pages:  0      plus 0 additional page(s)
Trailer pages:  0      plus 0 additional page(s)

Text string 1 in column:  0
_____

IGNORE text string

Text string 2 in column:  0
_____

Choice? + -
```

The program searches each page for one or two unique text strings that identify the banner page (see Appendix A for a banner page detection example). If you specify two strings, you must specify whether to find both strings or either string. Each string can be up to 64 characters long. You specify a range of line numbers and the program searches only those lines.

Besides specifying the banner page recognition parameters, you must also specify how many header and trailer banner pages each print job has.

Remove banner pages after processing?

Specify whether to remove banner pages from the file after PRINT/CHANNEL extracts routing information and before it routes the file.

No Default. Do not remove banner pages.

Yes Remove banner pages after PRINT/CHANNEL extracts information from them.

Starting line:

Specify the first line the program should search while it looks for banner page text. If you enter **0**, PRINT/CHANNEL disables banner recognition.

Number of lines:

Specify how many lines (beginning with **Starting line**) the software should search. The default is **1**.

Header pages:

Specify how many header banner pages each print job has. If the program does not encounter header banner pages at the beginning of a print job, PRINT/CHANNEL assumes the job has begun and begins looking for trailer banner pages. Because no header pages were identified, no job parameters are extracted. If you set **Remove banner pages after processing** to **Yes**, no data at the beginning of the job is removed because no header is identified.

Trailer pages:

Specify how many trailer banner pages each print job has. If the trailer differs from the header, use text string 2 with the **OR** or **TRAILER** option. PRINT/CHANNEL processes the data stream more efficiently when you specify trailer pages.

plus 0 additional page(s)

Number of additional pages following the detected banner page that form the logical header or trailer.

Text string 1 in column:

These fields define the first text string used to identify a banner page. Enter the beginning column number for the string and then the text string in the following field. A question mark is treated as a wildcard character and matches any print character in the corresponding position.

IGNORE|AND|OR|TRAILER text string

Specify how to use the second text string.

IGNORE

If you specify **I G N O R E**, PRINT/CHANNEL uses only text string 1.

AND If you specify **A N D**, PRINT/CHANNEL must find both text string 1 and text string 2 before it recognizes a banner page.

OR If you specify **O R**, PRINT/CHANNEL must find either text string 1 or text string 2 before it recognizes a banner page.

TRAILER

If you specify **T R A I L E R**, PRINT/CHANNEL uses text string 1 to identify a header banner page and text string 2 to identify a trailer banner page. PRINT/CHANNEL processes the data stream more efficiently when you specify trailer pages.

Text string 2 in column:

See the **Text string 1 in column** explanation.

Banner Extraction Information

When you press **Enter**, the PRINT/CHANNEL Printer Definition screen displays again with print job parameter extraction information.

```

                                PRINT/CHANNEL Printer Definition

Printer address:                OE
Enable or Disable device? Enabled
.....
                                Print Job Parameter Extraction Information

(These parameters are extracted from the first page of
the job. This will be the first banner page if present.)

Line numbers are relative and are measured BEFORE or
AFTER the banner text matching line.

      Acquire  Line    Beg Col  End Col
Job name:   NO     0      0        0
Form name:  NO     0      0        0
FCB name:   NO     0      0        0
Copies:     NO     0      0        0
Priority:    NO     0      0
Class:      NO     0      0

                                Choice? + -

```

This screen tells PRINT/CHANNEL where to find the **Job name**, **Form name**, **FCB name**, **Copies**, **Priority**, and **Class** parameters. PRINT/CHANNEL acquires these parameters from the first header banner page. You specify their location relative to the first line that meets the banner text matching criteria.

The **Acquire** field specifies whether to locate the parameter **BEFORE** or **AFTER** the matching criteria line. The **Line** field specifies how many lines before or after and the **Beg Col** and **End Col** fields specify where the parameter is located in the line. If you set **Acquire** to **No**, PRINT/CHANNEL uses a default value for that parameter.

- Press when you finish entering job parameter information.

The PRINT/CHANNEL Description screen displays for you to define the next printer.

2.2 Define the Adapter

To define the adapter, start at the PRINT/CHANNEL Print Sessions screen.

```
PRINT/CHANNEL Print Sessions

Address  Name      State
0E      CH0E     Enabled
0E      CH0F     Enabled
10      CH10     Enabled
11      CH11     Enabled
12      CH12     Enabled
13      CH13     Enabled
14      CH14     Enabled
15      CH15     Enabled

Escape

Adapter Description
```

➤ Select Adapter Description

The Adapter Description screen displays.

```
Adapter Description

Device Address?  280
Interrupt request? IRQ11
DMA request?     5

Transfer mode?   High Speed Transfer (HST)
Run diagnostics? No

Choice? + -
```

Device Address?

PC address for the CHANNEL adapter. The address you set here must match the device address jumper setting on the adapter card. The default setting on the adapter and in the software is **2 8 0**. Other choices are **2 9 0**, **2 A 0**, or **2 B 0**.

Note: Change the default setting only if you verify a conflict with other equipment settings in the PC.

Interrupt request?

Hardware line over which the processor and adapter communicate. The IRQ carries signals to get the processor's attention when the adapter is ready to receive or send information. The default IRQ request is **IRQ11**. Other choices are **IRQ10**, **IRQ12**, or **IRQ15**.

Note: Change the default setting only if you verify a conflict with other equipment settings in the PC.

DMA request?

Channel over which the adapter directly accesses memory. The default setting is **5**. Other choices are **6**, **7**, or **0**.

Note: Change the default setting only if you verify a conflict with other equipment settings in the PC.

Transfer mode?

Protocol for transferring data on the channel. You can choose from two protocols.

High Speed Transfer (HST)

Default. The adapter uses two signal pairs (Service In, Service Out and Data In, Data Out) to communicate with the host during data transfer. HST is also called Double Tag or Four Tag.

DC Interlock (DCI)

Direct-coupled interlock. The adapter uses one signal pair (Service In, Service Out) to communicate with the host during data transfer. This method is not recommended because it is slower. DCI is commonly known as Single Tag or Two Tag.

Run diagnostics?

You can select whether to run diagnostics.

No Default. Do not run diagnostics.

Yes Run diagnostics.

If you choose **Yes** to run diagnostics, the Channel Diagnostics screen displays. See Chapter 4 for more information about running diagnostics.

If you press **Enter** from the Adapter Description screen after you install the adapter, the following message displays:

```
Adapter Description

Device Address? 280
Interrupt request? IRQ11
DMA request? 5

Transfer mode? High Speed Transfer (HST)
Run diagnostics? No

BARR/CHANNEL adapter found at device address 280.

Adapter using IRQ11. IRQ test passed.

Adapter using DMA level 5. DMA transfer test passed.

Any key
```

If you did not install an adapter, the following message displays:

Adapter Description	
Device Address?	280
Interrupt request?	IRQ11
DMA request?	5
Transfer mode?	High Speed Transfer (HST)
Run diagnostics?	No

Adapter not found, Device Address does not match the jumper setting on the adapter, an address conflict exists with another adapter, or BBF file was not found. Insure that the BBF files are located in the same directory as the EXE file and that the Device Address is set correctly and does not conflict with another adapter in the PC.

Any key

2.3 Assign Devices

After you define the adapter, you need to direct the PRINT/CHANNEL output to destination devices. Start at the Installation Description menu.

Installation Description
PRINT/CHANNEL Description
Devices and Printers: LPT, COM, NET, SEND, LAN
Print Spool Description
<u>Assign Devices</u>
Monitor and Adapter
Startup Screen Notes
Tuning and Global Options
Exit and Save Changes

Selection ↑↓←→

1. Select **Assign Devices**.

This example assumes you have already set up your print spool description. To enable a spool printer, choose **Print Spool Description** from the Installation Description menu. For more information, see the *BARR/SPOOL* manual.

The PRINT/CHANNEL sessions you specified in the PRINT/CHANNEL Description appear on the Assign Devices screen as source devices.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CH0E-SUSPEND CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Select SOURCE-DESTINATION.  Escape  Selection ↑↓←→

```

2. Select **CH0E**.

BARR/SPOOL allows you to spool print files received via PRINT/CHANNEL. The following steps show you how to assign the source device **CH0E** to the destination device **SPOOL**.

```

Assign Devices

DESTINATION? (FILE) SCREEN NUL SUSPEND LPT1 SPOOL
Selection ↑↓←→

```

3. Select **SPOOL** as the destination.

```

Assign Devices

Beginning of file name: PCH
Ending of file name is jobname.  New File  Log  Enter character

```

4. Enter the beginning of the file name for the print file in the spool directory (PCH in the example) and press **Enter**.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CH0E-SPOOL CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Continue  Escape  Receive mode  Options  Help

```

5. Notice **CH0E** now has a destination of **SPOOL**.

Your *BARR/SPOOL* manual contains more information about spooling.

Receive Mode

Receive mode controls how the software handles files received on the PC. To reach the receive mode choices, start at the Assign Devices screen.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
Continue  Escape  Receive mode  Options  Help
```

➤ Select **Receive mode**.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SPOOL CH11-SUSPEND
CH12-SUSPEND  CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
ASCII  N ASCII lines Variable ASCII lines  Transfer files  Transparent
Binary DOS (obsolete) Fixed length   S/390 Channel PostScript !!--
```

The following receive modes apply to data received with PRINT/CHANNEL:

ASCII

Default. ASCII is the format used on the PC and is required for files printed on an ASCII printer. If the original file is in EBCDIC format, PRINT/CHANNEL converts it to ASCII format with the ASCII carriage control codes carriage return (CR), line feed (LF), and form feed (FF). The EBCDIC format is used by host computers. See the ASCII and EBCDIC Standards appendix in your *BARR/SPOOL* manual.

N ASCII lines

You can use this receive mode to receive files with fixed-length records longer than 80 characters. (Each fixed-length record has the same length.) Some host systems can transfer only 80-character records. **N ASCII lines** allows you to work around this limitation. For records that are not an even multiple of 80 characters, or have a length greater than 720 characters, **Variable ASCII lines** might be a better choice.

To use **N ASCII lines**, you must write a host program to divide each dataset record into groups of 80-character lines. You must divide each record into the same number of lines (from 1 to 9) so that all records have the same length. After the PC receives the 80-character lines, the software rebuilds each record by combining the specified number of lines. The software converts EBCDIC data from the host to ASCII format with carriage return and line feed (CR LF) to indicate the end of each record, but no form feeds (FF) to indicate page boundaries.

When you select **N ASCII lines**, PRINT/CHANNEL prompts you to specify the number of 80-character lines to combine into one record. Choices are 1 to 9, where 9 allows a maximum record length of 720 characters.

Variable ASCII lines

When you receive variable-length or fixed-length records shorter or longer than 80 characters, this receive mode might be useful. Variable-length records have different lengths. Some host systems can transfer only 80-character records. If you need to transfer records with a different length, the **Variable ASCII lines** selection allows you to work around this limitation. If records are an even multiple of 80 characters (for example, 160 or 240), **N ASCII lines** might be a better choice.

With the **Variable ASCII lines** selection, the software receives 80-character records from the host and rebuilds them to their original lengths. The software converts EBCDIC data from the host to ASCII format with carriage return and line feed (CR LF) to indicate the end of each record, but no form feeds (FF) to indicate page boundaries.

To use this feature, write a host program to divide all records into 80-character lines. The last portion of the record can have less than 80 characters if the record length is not an even multiple of 80. The host program must insert an EBCDIC vertical bar (|) or hexadecimal 4F at the end of each record.

For example, you would divide a 120-character record into two parts: an 80-character line and a 40-character line that ends in a vertical bar. After the PC receives the data, the

software rebuilds each record by combining lines until it encounters a vertical bar. The software discards the vertical bar and any blanks added to pad the last portion of the record to 80 bytes.

Transparent

Transparent receive mode allows you to use the SCS Enabler option on the Xerox 3700 printer and the EBCDIC Parallel Meta/GHO Enabler-IB option on the Xerox 4235 printer.

Binary

Binary receive mode does not alter bytes in the data stream. Use this receive mode if you want the PRINT/CHANNEL data stream to remain unmodified.

Fixed length

Use this option for special applications, usually situations that require the received data to contain fixed-length records. (Fixed-length records have the same length.) Applications for the **Fixed length** option include receiving data to magnetic tape and receiving data to be processed by a PC program.

For the SEND1 to SEND2, LAN1 to LAN4, and SPOOL1 to SPOOL8 source devices, **Fixed length** is the only supported receive mode. You would only choose it for these devices when you write to magnetic tape.

When you select **Fixed length**, additional options display on the bottom of the screen. See the Assign Devices chapter in your *BARR/SPOOL* manual for more information.

S/390 Channel

PRINT/CHANNEL converts data to the Barr S/390 Channel format, which you must use with the PRINT370 option. When you receive data you want to send to a channel printer, you must set the receive mode to **S/390 Channel** and set **Carriage control** to **normal**. PRINT/CHANNEL passes data in the FCB record to the destination with no alterations.

PostScript

PostScript receive mode converts EBCDIC files to PostScript for printing to PostScript printers. You must use the form overlay files **PORTRAIT**, **LAND**, and **2UP** provided in the directory `C:\BARR\REF\PSOVL\` with **PostScript** receive mode. The overlay files set the printer to the desired mode and define macros used by PostScript.

This mode encloses data converted to PostScript format in parentheses. It converts carriage control such as **CR**, **LF**, and **FF** to macro calls controlled by the overlay file. It places carriage control between data lines.

You can use **PostScript** receive mode only with source devices that support receive modes (such as **LANN**) and with destination devices that support form overlays (including **LPTn**, **COMn**, and **NETn**).

The overlay files contain some options you can change by editing the overlay file. After you edit with a program editor, place the overlay files in the forms overlay directory defined on the Tuning and Global Options, Printer Control screen. To activate the overlay, include the name of the overlay file in the file header.

Note: With **PostScript** receive mode, you cannot process files received from destinations other than a host. If you want to print files from other sources in PostScript format, the files must already be in PostScript format before you receive them to the PC.

Receive Mode Example

The following example shows you how to assign **S/390 Channel** receive mode to the data received on printer session **CH0E**.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Continue  Escape  Receive mode  Options  Help

```

1. Select **Receive mode**.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SPOOL CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

ASCII N ASCII lines Variable ASCII lines Transfer files Transparent
Binary DOS (obsolete) Fixed length  S/390 Channel PostScript !!→

```

2. Select **S/390 Channel**.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CHOE-SPOOL* CHOF-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Carriage control: normal

Choice? + -

```

3. Select **normal** for carriage control.

```

Assign Devices

LOG-NUL SPOOL1-LPT1 CHOE-SPOOL* CHOF-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Continue  Escape  Receive mode  Options  Help

```

The screen displays an asterisk next to the destination device when you select a receive mode other than ASCII.

Options

Several options control how to display form information as file attributes on the Print Spool screen.

- From the Assign Devices screen, select **Options** to display the options described below.

Assign Devices

ASCII data with ASA carriage control? No
OUTPUT statement used in file? No Class: K Spool header from data? No
Ignore 0 lines from start of file. Strip spool header? No
Choice? + -

ASCII data with ASA carriage control?

Specify whether to receive ASCII files with ASA carriage control and write them to S/390 printers. You must also enable the spool header by directing the file to the print spool and setting **Receive mode** to **ASCII**. If you set (**FILE**) as the destination, you must set **Write spool header to file** to **Yes** (see the Assign Devices chapter in your *BARR/SPOOL* manual).

No Default. Do not support ASA carriage control.

Yes Receive files with ASA carriage control and convert ASA to machine carriage control.

OUTPUT statement used in file?

You can use the Barr OUTPUT statement to provide information typically used for printing a file such as job name, form name, file name, copies, priority, and class. You insert the information in the file before you receive the file to the PC. PRINT/CHANNEL extracts it from the file, stores it in the spool header, and displays it on the Print Spool screen.

The OUTPUT statement is useful when other methods for obtaining print instructions are not available. (Do not confuse the Barr OUTPUT statement with the JCL output statement, which has a different purpose.) If the data source is a host computer, you can use options such as the JES2 \$HASP190 message or SETUPHDR (PDIR) record to obtain this information. The OUTPUT statement is not valid for the **SENDn** or **LANn** devices.

Note: To use this feature, you must change the program that produces the data so it adds the OUTPUT statement to the data file.

No Default. The OUTPUT statement is not used.

Yes The information from the OUTPUT statement is extracted from the file and stored in the spool header. Remember to include the OUTPUT statement in the file before the file is received to the PC.

- When you enable the OUTPUT statement, all lines up to and including the OUTPUT statement are deleted from the file. To prevent data loss, put the OUTPUT statement at the beginning of the file, before any data.

Note: If the file does not include the OUTPUT statement, all data from the file is deleted and a warning message displays on the console.

- In the OUTPUT statement, the word **OUTPUT** must begin in column 1, column 7 must be blank, and the keyword for the first option must begin in column 8. The statement must fit on one line in the file. It cannot wrap to the next line. If the file's maximum line length is limited to 80 characters, you might not be able to specify all options. Use these keywords to set options in the OUTPUT statement and substitute the option value for n: **FILENAME=n** **JOBNAME=n** **FORMNAME=n** **FCBNAME=n** **COPIES=n** **PRIORITY=n** **CLASS=n** (You cannot abbreviate the keywords.)
- Specify only the options you need. You can list the options in any order. For example:

```
OUTPUT FORMNAME=taxes FILENAME=taxdata
```

- If you specify **FILENAME=**, its value will be used as the **Ending of file name**
- You can use the **Ending of file name is from file** feature to obtain the file name from file text and use the OUTPUT statement to supply other options. For example, you can use **Ending of file name is from file** to extract the file name from the banner page and use the OUTPUT statement to assign a form name.
- If you specify an invalid file name, the software assigns the file name **ERROR** and displays an error message on the console.

When you include **FORMNAME=** in the OUTPUT statement, you also must use the Barr Edit Forms feature or the form name will be discarded. PRINT/CHANNEL searches for a user-defined form that matches the form name in the OUTPUT statement. If it does not find a user-defined form, the software displays this message:

**OUTPUT statement received but form nnnnnnnn
not found.**

The form name in the spool header is set to blank, but any other OUTPUT statement fields are applied.

- You can use the **Ignore n lines from start of file** option with the OUTPUT statement.

Class:

Use this option to assign a new default output class to files received on the given source device. The selected **Class** value appears as an attribute for the file on the Print Spool screen. You can set **Class** differently for each source device. Defaults are **K** to **R**, which correspond to printers 1 to 8.

Spool header from data?

This option controls whether the formname or jobname for the spool header is extracted from a text line within a file when you receive the file.

No Default. PRINT/CHANNEL does not extract the spool header information from the file.

Yes You can extract the formname or jobname from a specified location in the file and place it in the spool header. You can choose **formname** or **jobname** and enter the **page**, **line**, and **column** numbers where the name appears in the file.

PRINT/CHANNEL places a spool header in all files input through this source device. In the header, the software takes formname or jobname from the data, sets class from the **Class** option, and leaves all other fields at default values.

Spool header from data is a valid option when you select either the **ASCII** or **S/390 Channel** receive mode.

If you select **Yes**, the software displays the following screen:

Assign Devices
Spool header's <u>formname</u> is on page <u> 0 </u> , line <u> 0 </u> in columns <u> 0 </u> to <u> 0 </u> . Choice? + -

In exceptional cases, you might not be able to obtain a formname or jobname by any of the usual options. In these cases you can use **Spool header from data** with **Class** to assign a one-character formname. To do this, set **Class** to a unique value, set **Spool header from data** to **Yes**, and then set **page** number to zero.

PRINT/CHANNEL uses the one-character **Class** value as the formname and displays it on the Print Spool screen as the formname for the file. You can then use the formname as criteria for determining when to print the files or you can create a forms overlay file of the same name to load printer control data. Several other header options are available, so use this special feature only as a last resort.

Ignore n lines from start of file.

This option specifies the number of lines (**n**) to delete from the start of a file when the spool receives the file. A common application is to delete the first two records of a punch file because they contain a blank card and a file separator card. The maximum value is **3 2 7 6 7** lines.

Strip spool header?

When you write files to disk, you can remove spool headers from the files. This option only displays when the destination is **SPOOL** or **(FILE)**. If you strip the spool header when the destination is **SPOOL**, the file has no header information and is assigned a class of **Z**. The most useful application is to set the option to **Yes** for **SPOOL1→(FILE)** so the print spool uses the header information to route the file via a spool printer (**SPOOL1**), but does not preserve the header in the final destination on disk.

No Default. Do not strip the spool header.

Yes Remove the spool header from the file.

Notes:


Configure the PRINT/CHANNEL Software (PCI Adapter)

The Installation chapter in your *BARR/SPOOL* manual describes how to configure software from the Installation Description menu. This chapter discusses additional PRINT/CHANNEL options you need to specify and includes sample BARR/SPOOL and PRINT370 screens.

To run the Barr software, type the Barr software startup command followed by the letter **i** at the DOS prompt. For example, type the following:

```
spool i
```

The Installation Description menu displays.



- To configure the PRINT/CHANNEL settings, select **PRINT/CHANNEL Description**

3.1 Define Print Sessions and Addresses

You define the number of print sessions and first printer address on the PRINT/CHANNEL Description screen.

Description Option

```
PRINT/CHANNEL Description

Mainframe print sessions:  8

Enter number
```

Mainframe print sessions:

Enter 1 to 8 printers. This is the number of channel printers you want the Barr software to emulate. This manual shows eight printer sessions.

Print Session Options

1. Press **Enter** to display a list of all printers.

```
PRINT/CHANNEL Print Sessions

Address  Name      State
-----  -
OE       CH0E      Enabled
OF       CH0F      Enabled
10       CH10      Enabled
11       CH11      Enabled
12       CH12      Enabled
13       CH13      Enabled
14       CH14      Enabled
15       CH15      Enabled

Escape

Adapter Description
```

2. To define a printer, select it from the list.

Printer Definition Options

The PRINT/CHANNEL Printer Definition screen displays.

PRINT/CHANNEL Printer Definition

Printer address: 0E
Enable or Disable device? Enabled

EOF timeout in seconds (0 for none): 30
Intervention timeout in seconds: 10
Enforce UCS Size? No UCS Size: 512
Suspend EOF timeout after FCB? No

Job separation by banner page recognition? Yes

Choice? + -

Printer address:

The printer address in hexadecimal. Each printer must have a unique address. This address must match the subchannel address at the host. You can enter an address in the range from **0 0** to **F F**.

Enable or Disable device?

You can enable or disable the device to control its use.

Enabled

Default. The device is online.

Disabled

The device is offline.

EOF timeout in seconds (0 for none):

If the software receives no print data from the host for the specified length of time, it assumes the current print job is complete. The default is 30 seconds.

Intervention timeout in seconds:

This flow control tuning option can help reduce or eliminate unnecessary intervention messages on the host console. PRINT/CHANNEL might need to temporarily stop receiving data from the host. For example, if a PRINT/CHANNEL printer is directly connected to an output device and that device enters an intervention state, the data flow from the host must be suspended. It also might be necessary to stop receiving data while the program searches a large spool retain directory. While the program builds the retain file list, it suspends normal data flow.

When PRINT/CHANNEL detects the need to temporarily suspend data reception, it withholds sending a device end (DE) acknowledgment to the host. This normal action does not cause problems if DE is not withheld for too long.

You can configure the time limit on the host. Typically you would specify from 30 seconds to a few minutes. The PRINT/CHANNEL configuration option, **Intervention timeout in seconds**, tells the program how long to withhold DE from the host. The default value is **10** seconds. Then the program supplies the DE to the host (thereby avoiding a missing DE interrupt) and enters the Not Ready state. The program rejects the next command from the host with an Intervention Required (not ready) sense. When the reason for suspending data flow is resolved, PRINT/CHANNEL enters the ready state and supplies a DE to the host. Normal data flow resumes.

If you receive **intervention required** messages (on the host console and the BARR/SPOOL Operations screen) and the messages are considered normal for your situation, you might be able to eliminate the messages by increasing the **Intervention timeout in seconds** value. Changing this value is merely cosmetic and will neither increase nor decrease your data throughput. Your mainframe operator might ignore these messages anyway knowing that you are already taking care of the problem.

Enforce UCS Size?

Specify whether the received Universal Character Set (UCS) is limited to a specific size.

- No** Default. PRINT/CHANNEL can receive any size UCS from the host.
- Yes** PRINT/CHANNEL can only receive up to the value set for UCS size. The UCS maps EBCDIC characters to print-chain positions. Because the PRINT/CHANNEL emulation does not contain a physical print chain, the program ignores the information contained in this command. Some host configurations detect an error unless the printer device accepts only a specified length UCS. By default, this length is 512 bytes. If your host requires this behavior, you should enable the **Enforce UCS Size** option and enter the actual size of the UCS your host sends.

UCS Size:

Specify the UCS size PRINT/CHANNEL can receive. The default is **5 1 2**. This option applies only if you set **Enforce UCS Size** to **Yes**.

Suspend EOF timeout after FCB?

You can use this option to temporarily suspend EOF timeout processing after PRINT/CHANNEL receives an FCB.

- No** Default. EOF timeout processing is not affected by receiving an FCB.
- Yes** PRINT/CHANNEL temporarily suspends the EOF timeout operation after it receives an FCB from the host. Normal EOF timeout processing resumes when PRINT/CHANNEL detects the end of the current page.

Job separation by banner page recognition?

Specify whether to perform print job separation by banner recognition.

- Yes** Default. The program performs print job separation by recognizing banner pages.

No Disable banner page recognition. You can only separate print jobs by timeout or a received FCB.

Copy PRINT/CHANNEL copies the banner recognition and spool parameter extraction information from the previous printer definition. This option only applies if you define more than one printer.

If you select **Yes** or **Copy**, the PRINT/CHANNEL Printer Definition screen displays again with banner recognition information.

Banner Recognition Options

```
PRINT/CHANNEL Printer Definition

Printer address:      0E
Enable or Disable device? Enabled
.....
Banner Recognition Information

Remove banner pages after processing? No

Starting line:  0      Number of lines:  1
Header pages:  0      plus 0 additional page(s)
Trailer pages:  0      plus 0 additional page(s)

Text string 1 in column:  0

-----
IGNORE text string
Text string 2 in column:  0

-----
Choice? + -
```

The program searches each page for one or two unique text strings that identify the banner page (see Appendix A for a banner page detection example). If you specify two strings, you must specify whether to find both strings or either string. Each string can be up to 64 characters long. You specify a range of line numbers and the program searches only those lines.

Besides specifying the banner page recognition parameters, you must also specify how many header and trailer banner pages each print job has.

Remove banner pages after processing?

Specify whether to remove banner pages from the file after PRINT/CHANNEL extracts routing information and before it routes the file.

No Default. Do not remove banner pages.

Yes Remove banner pages after PRINT/CHANNEL extracts information from them.

Starting line:

Specify the first line the program should search while it looks for banner page text. If you enter **0**, PRINT/CHANNEL disables banner recognition.

Number of lines:

Specify how many lines (beginning with **Starting line**) the software should search. The default is **1**.

Header pages:

Specify how many header banner pages each print job has. If the program does not encounter header banner pages at the beginning of a print job, PRINT/CHANNEL assumes the job has begun and begins looking for trailer banner pages. Because no header pages were identified, no job parameters are extracted. If you set **Remove banner pages after processing** to **Yes**, no data at the beginning of the job is removed because no header is identified.

Trailer pages:

Specify how many trailer banner pages each print job has. If the trailer differs from the header, use text string 2 with the **OR** or **TRAILER** option. PRINT/CHANNEL processes the data stream more efficiently when you specify trailer pages.

plus 0 additional page(s)

Number of additional pages following the detected banner page that form the logical header or trailer.

Text string 1 in column:

These fields define the first text string used to identify a banner page. Enter the beginning column number for the string and then the text string in the following field. A question mark is treated as a wildcard character and matches any print character in the corresponding position.

IGNORE|AND|OR|TRAILER text string

Specify how to use the second text string.

IGNORE

If you specify **IGNORE**, PRINT/CHANNEL uses only text string 1.

AND If you specify **AND**, PRINT/CHANNEL must find both text string 1 and text string 2 before it recognizes a banner page.

OR If you specify **OR**, PRINT/CHANNEL must find either text string 1 or text string 2 before it recognizes a banner page.

TRAILER

If you specify **TRAILER**, PRINT/CHANNEL uses text string 1 to identify a header banner page and text string 2 to identify a trailer banner page. PRINT/CHANNEL processes the data stream more efficiently when you specify trailer pages.

Text string 2 in column:

See the **Text string 1 in column** explanation.

Banner Extraction Information

When you press **Enter**, the PRINT/CHANNEL Printer Definition screen displays again with print job parameter extraction information.

```

                                PRINT/CHANNEL Printer Definition

Printer address:                0E
Enable or Disable device? Enabled
.....
                                Print Job Parameter Extraction Information

(These parameters are extracted from the first page of
the job. This will be the first banner page if present.)

Line numbers are relative and are measured BEFORE or
AFTER the banner text matching line.

      Acquire  Line   Beg Col  End Col
Job name:   NO    0    0    0
Form name:  NO    0    0    0
FCB name:   NO    0    0    0
Copies:     NO    0    0    0
Priority:    NO    0    0    0
Class:      NO    0    0    0

                                Choice? + -

```

This screen tells PRINT/CHANNEL where to find the **Job name**, **Form name**, **FCB name**, **Copies**, **Priority**, and **Class** parameters. PRINT/CHANNEL acquires these parameters from the first header banner page. You specify their location relative to the first line that meets the banner text matching criteria.

The **Acquire** field specifies whether to locate the parameter **BEFORE** or **AFTER** the matching criteria line. The **Line** field specifies how many lines before or after and the **Beg Col** and **End Col** fields specify where the parameter is located in the line. If you set **Acquire** to **No**, PRINT/CHANNEL uses a default value for that parameter.

- Press when you finish entering job parameter information.

The PRINT/CHANNEL Description screen displays for you to define the next printer.

3.2 Define the Adapter

To define the adapter, start at the PRINT/CHANNEL Print Sessions screen.

PRINT/CHANNEL Print Sessions		
Address	Name	State
0E	CH0E	Enabled
0F	CH0F	Enabled
10	CH10	Enabled
11	CH11	Enabled
12	CH12	Enabled
13	CH13	Enabled
14	CH14	Enabled
15	CH15	Enabled

Escape

Adapter Description

► Select Adapter Description

The Adapter Description screen displays.

Adapter Description	
Device Address?	<u>280</u>
Interrupt request?	<u>IRQ11</u>
DMA request?	<u>5</u>
Transfer mode?	<u>High Speed Transfer (HST)</u>
Run diagnostics?	<u>No</u>

Choice? + -

Device Address?

PC address for the CHANNEL adapter. You cannot access this field because the PCI BIOS automatically assigns this value.

Interrupt request?

Hardware line over which the processor and adapter communicate. You cannot access this field because the PCI BIOS automatically assigns this value.

DMA request?

Channel over which the adapter directly accesses memory. This field does not apply for a CHANNEL-IN (BT) adapter.

Transfer mode?

Protocol for transferring data on the channel. You can choose from four protocols.

High Speed Transfer (HST)

Default. The adapter uses two signal pairs (Service In, Service Out and Data In, Data Out) to communicate with the host during data transfer. HST is also called Double Tag or Four Tag.

3.0 MByte Data Streaming

The adapter communicates with the host via 3.0 MB data streaming.

4.5 MByte Data Streaming

The adapter communicates with the host via 4.5 MB data streaming.

DC Interlock (DCI)

Direct-coupled interlock. The adapter uses one signal pair (Service In, Service Out) to communicate with the host during data transfer. This method is not recommended because it is slower. DCI is commonly known as Single Tag or Two Tag.

Run diagnostics?

You can select whether to run diagnostics.

No Default. Do not run diagnostics.

Yes Run diagnostics.

If you choose **Yes** to run diagnostics, the Channel Diagnostics screen displays. See Chapter 4 for more information about running diagnostics.

If you press **Enter** from the Adapter Description screen after you install the adapter, the following message displays:

```
Adapter Description

Device Address?  280
Interrupt request? IRQ11
DMA request?     5

Transfer mode?   High Speed Transfer (HST)
Run diagnostics? No

BARR/CHANNEL adapter found at device address 280.

Adapter using IRQ11. IRQ test passed.

Adapter using DMA level 5. DMA transfer test passed.

Any key
```

If you did not install an adapter, the following message displays:

```

Adapter Description

Device Address?    280
Interrupt request? IRQ11
DMA request?      5

Transfer mode?    High Speed Transfer (HST)
Run diagnostics? No

Adapter not found, Device Address does not match the jumper
setting on the adapter, an address conflict exists with another
adapter, or BBF file was not found. Insure that the BBF files
are located in the same directory as the EXE file and that the
Device Address is set correctly and does not conflict with
another adapter in the PC.

Any key

```

Note: The BBF notes do not apply to the CHANNEL-IN (BT) adapter.

3.3 Assign Devices

After you define the adapter, you need to direct the PRINT/CHANNEL output to destination devices. Start at the Installation Description menu.

```

Installation Description

PRINT/CHANNEL Description
Devices and Printers: LPT, COM, NET, SEND, LAN
Print Spool Description
Assign Devices
Monitor and Adapter
Startup Screen Notes
Tuning and Global Options

Exit and Save Changes

Selection ↑↓←→

```

1. Select **Assign Devices**.

This example assumes you have already set up your print spool description. To enable a spool printer, choose **Print Spool Description** from the Installation Description menu. For more information, see the *BARR/SPOOL* manual.

The PRINT/CHANNEL sessions you specified in the PRINT/CHANNEL Description appear on the Assign Devices screen as source devices.

```
Assign Devices

LOG-NUL SPOOL1-LPT1 CH0E-SUSPEND CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Select SOURCE-DESTINATION.  Escape  Selection ↑↓←→
```

2. Select **CH0E**.

BARR/SPOOL allows you to spool print files received via PRINT/CHANNEL. The following steps show you how to assign the source device **CH0E** to the destination device **SPOOL**.

```
Assign Devices

DESTINATION? (FILE) SCREEN NUL SUSPEND LPT1 SPOOL
Selection ↑↓←→
```

3. Select **SPOOL** as the destination.

```
Assign Devices

Beginning of file name: PCH
Ending of file name is jobname.  New File  Log  Enter character
```

4. Enter the beginning of the file name for the print file in the spool directory (PCH in the example) and press **Enter**.

```
Assign Devices

LOG-NUL SPOOL1-LPT1 CH0E-SPOOL CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND

Continue  Escape  Receive mode  Options  Help
```

5. Notice **CH0E** now has a destination of **SPOOL**.

Your *BARR/SPOOL* manual contains more information about spooling.

Receive Mode

Receive mode controls how the software handles files received on the PC. To reach the receive mode choices, start at the Assign Devices screen.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
Continue  Escape  Receive mode  Options  Help
```

➤ Select **Receive mode**.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CHOE-SPOOL CHOF-SUSPEND CH10-SPOOL CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
ASCII N ASCII lines Variable ASCII lines Transfer files Transparent
Binary DOS (obsolete) Fixed length S/390 Channel PostScript ↑↓→←
```

The following receive modes apply to data received with PRINT/CHANNEL:

ASCII

Default. ASCII is the format used on the PC and is required for files printed on an ASCII printer. If the original file is in EBCDIC format, PRINT/CHANNEL converts it to ASCII format with the ASCII carriage control codes carriage return (CR), line feed (LF), and form feed (FF). The EBCDIC format is used by host computers. See the ASCII and EBCDIC Standards appendix in your *BARR/SPOOL* manual.

N ASCII lines

You can use this receive mode to receive files with fixed-length records longer than 80 characters. (Each fixed-length record has the same length.) Some host systems can transfer only 80-character records. **N ASCII lines** allows you to work around this limitation. For records that are

not an even multiple of 80 characters, or have a length greater than 720 characters, **Variable ASCII lines** might be a better choice.

To use **N ASCII lines**, you must write a host program to divide each dataset record into groups of 80-character lines. You must divide each record into the same number of lines (from 1 to 9) so that all records have the same length. After the PC receives the 80-character lines, the software rebuilds each record by combining the specified number of lines. The software converts EBCDIC data from the host to ASCII format with carriage return and line feed (CR LF) to indicate the end of each record, but no form feeds (FF) to indicate page boundaries.

When you select **N ASCII lines**, PRINT/CHANNEL prompts you to specify the number of 80-character lines to combine into one record. Choices are 1 to 9, where 9 allows a maximum record length of 720 characters.

Variable ASCII lines

When you receive variable-length or fixed-length records shorter or longer than 80 characters, this receive mode might be useful. Variable-length records have different lengths. Some host systems can transfer only 80-character records. If you need to transfer records with a different length, the **Variable ASCII lines** selection allows you to work around this limitation. If records are an even multiple of 80 characters (for example, 160 or 240), **N ASCII lines** might be a better choice.

With the **Variable ASCII lines** selection, the software receives 80-character records from the host and rebuilds them to their original lengths. The software converts EBCDIC data from the host to ASCII format with carriage return and line feed (CR LF) to indicate the end of each record, but no form feeds (FF) to indicate page boundaries.

To use this feature, write a host program to divide all records into 80-character lines. The last portion of the record can have less than 80 characters if the record length is not an even multiple of 80. The host program must insert an EBCDIC vertical bar (|) or hexadecimal 4F at the end of each record.

For example, you would divide a 120-character record into two parts: an 80-character line and a 40-character line that ends in a vertical bar. After the PC receives the data, the software rebuilds each record by combining lines until it encounters a vertical bar. The software discards the vertical bar and any blanks added to pad the last portion of the record to 80 bytes.

Transparent

Transparent receive mode allows you to use the SCS Enabler option on the Xerox 3700 printer and the EBCDIC Parallel Meta/GHO Enabler-IB option on the Xerox 4235 printer.

Binary

Binary receive mode does not alter bytes in the data stream. Use this receive mode if you want the PRINT/CHANNEL data stream to remain unmodified.

Fixed length

Use this option for special applications, usually situations that require the received data to contain fixed-length records. (Fixed-length records have the same length.) Applications for the **Fixed length** option include receiving data to magnetic tape and receiving data to be processed by a PC program.

For the SEND1 to SEND2, LAN1 to LAN4, and SPOOL1 to SPOOL8 source devices, **Fixed length** is the only supported receive mode. You would only choose it for these devices when you write to magnetic tape.

When you select **Fixed length**, additional options display on the bottom of the screen. See the Assign Devices chapter in your *BARR/SPOOL* manual for more information.

S/390 Channel

PRINT/CHANNEL converts data to the Barr S/390 Channel format, which you must use with the PRINT370 option. When you receive data you want to send to a channel printer, you must set the receive mode to **S / 390 Channel** and set **Carriage control** to **normal**.

PostScript

PostScript receive mode converts EBCDIC files to PostScript for printing to PostScript printers. You must use the form overlay files PORTRAIT, LAND, and 2UP provided in the directory C:\BARR\REF\PSOVL\ with **PostScript** receive mode. The overlay files set the printer to the desired mode and define macros used by PostScript.

This mode encloses data converted to PostScript format in parentheses. It converts carriage control such as CR, LF, and FF to macro calls controlled by the overlay file. It places carriage control between data lines.

You can use **PostScript** receive mode only with source devices that support receive modes (such as **LANN**) and with destination devices that support form overlays (including **LPTn**, **COMn**, and **NETn**).

The overlay files contain some options you can change by editing the overlay file. After you edit with a program editor, place the overlay files in the forms overlay directory defined on the Tuning and Global Options, Printer Control screen. To activate the overlay, include the name of the overlay file in the file header.

Note: With **PostScript** receive mode, you cannot process files received from destinations other than a host. If you want to print files from other sources in PostScript format, the files must already be in PostScript format before you receive them to the PC.

Receive Mode Example

The following example shows you how to assign **S/390 Channel** receive mode to the data received on printer session **CH0E**.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CH0E-SPOOL CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
Continue  Escape  Receive mode  Options  Help
```

1. Select **Receive mode**.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CH0E-SPOOL CH0F-SUSPEND CH10-SPOOL CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
ASCII N ASCII lines Variable ASCII lines Transfer files Transparent
Binary DOS (obsolete) Fixed length S/390 Channel PostScript ↑↓←→
```

2. Select **S/390 Channel**.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CH0E-SPOOL* CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
Carriage control: normal
Choice? + -
```

3. Select **normal** for carriage control.

```
Assign Devices
LOG-NUL SPOOL1-LPT1 CH0E-SPOOL* CH0F-SUSPEND CH10-SUSPEND CH11-SUSPEND
CH12-SUSPEND CH13-SUSPEND CH14-SUSPEND CH15-SUSPEND
Continue  Escape  Receive mode  Options  Help
```

The screen displays an asterisk next to the destination device when you select a receive mode other than ASCII.

Options

Several options control how to display form information as file attributes on the Print Spool screen.

- From the Assign Devices screen, select **Options** to display the options described below.

Assign Devices	
ASCII data with ASA carriage control?	<u>No</u>
OUTPUT statement used in file?	<u>No</u> Class: <u>K</u> Spool header from data?
Ignore <u> 0</u> lines from start of file. Strip spool header?	<u>No</u>
	Choice? + -

ASCII data with ASA carriage control?

Specify whether to receive ASCII files with ASA carriage control and write them to S/370 printers. You must also enable the spool header by directing the file to the print spool and setting **Receive mode** to **ASCII**. If you set (**FILE**) as the destination, you must set **Write spool header to file** to **Yes** (see the Assign Devices chapter in your *BARR/SPOOL* manual).

No Default. Do not support ASA carriage control.

Yes Receive files with ASA carriage control and convert ASA to machine carriage control.

OUTPUT statement used in file?

You can use the Barr OUTPUT statement to provide information typically used for printing a file such as job name, form name, file name, copies, priority, and class. You insert the information in the file before you receive the file to the PC. PRINT/CHANNEL extracts it from the file, stores it in the spool header, and displays it on the Print Spool screen.

The OUTPUT statement is useful when other methods for obtaining print instructions are not available. (Do not confuse the Barr OUTPUT statement with the JCL output statement, which has a different purpose.) If the data source is a host computer, you can use options such as the

JES2 \$HASP190 message or SETUPHDR (PDIR) record to obtain this information. The OUTPUT statement is not valid for the **SENDn** or **LANn** devices.

Note: To use this feature, you must change the program that produces the data so it adds the OUTPUT statement to the data file.

No Default. The OUTPUT statement is not used.

Yes The information from the OUTPUT statement is extracted from the file and stored in the spool header. Remember to include the OUTPUT statement in the file before the file is received to the PC.

- When you enable the OUTPUT statement, all lines up to and including the OUTPUT statement are deleted from the file. To prevent data loss, put the OUTPUT statement at the beginning of the file, before any data.

Note: If the file does not include the OUTPUT statement, all data from the file is deleted and a warning message displays on the console.

- In the OUTPUT statement, the word **OUTPUT** must begin in column 1, column 7 must be blank, and the keyword for the first option must begin in column 8. The statement must fit on one line in the file. It cannot wrap to the next line. If the file's maximum line length is limited to 80 characters, you might not be able to specify all options. Use these keywords to set options in the OUTPUT statement and substitute the option value for n: **FILENAME=n** **JOBNAME=n** **FORMNAME=n** **FCBNAME=n** **COPIES=n** **PRIORITY=n** **CLASS=n** (You cannot abbreviate the keywords.)
- Specify only the options you need. You can list the options in any order. For example:

```
OUTPUT FORMNAME=taxes FILENAME=taxdata
```

- If you specify **FILENAME=**, its value will be used as the **Ending of file name**.

- You can use the **Ending of file name is from file** feature to obtain the file name from file text and use the **OUTPUT** statement to supply other options. For example, you can use **Ending of file name is from file** to extract the file name from the banner page and use the **OUTPUT** statement to assign a form name.
- If you specify an invalid file name, the software assigns the file name **ERROR** and displays an error message on the console.

When you include **FORMNAME=** in the **OUTPUT** statement, you also must use the Barr Edit Forms feature or the form name will be discarded. **PRINT/CHANNEL** searches for a user-defined form that matches the form name in the **OUTPUT** statement. If it does not find a user-defined form, the software displays this message:

```
OUTPUT statement received but form nnnnnnnn not found.
```

The form name in the spool header is set to blank, but any other **OUTPUT** statement fields are applied.

- You can use the **Ignore n lines from start of file** option with the **OUTPUT** statement.

Class:

Use this option to assign a new default output class to files received on the given source device. The selected **Class** value appears as an attribute for the file on the Print Spool screen. You can set **Class** differently for each source device. Defaults are **K** to **R**, which correspond to printers **1** to **8**.

Spool header from data?

This option controls whether the formname or jobname for the spool header is extracted from a text line within a file when you receive the file.

- No** Default. **PRINT/CHANNEL** does not extract the spool header information from the file.

Yes You can extract the formname or jobname from a specified location in the file and place it in the spool header. You can choose **formname** or **jobname** and enter the **page**, **line**, and **column** numbers where the name appears in the file.

PRINT/CHANNEL places a spool header in all files input through this source device. In the header, the software takes formname or jobname from the data, sets class from the **Class** option, and leaves all other fields at default values.

Spool header from data is a valid option when you select either the **ASCII** or **S/390 Channel** receive mode.

If you select **Yes**, the software displays the following screen:

Assign Devices
Spool header's <u>formname</u> is on page <u> 0 </u> , line <u> 0 </u> in columns <u> 0 </u> to <u> 0 </u> . Choice? + -

In exceptional cases, you might not be able to obtain a formname or jobname by any of the usual options. In these cases you can use **Spool header from data** with **Class** to assign a one-character formname. To do this, set **Class** to a unique value, set **Spool header from data** to **Yes**, and then set **page** number to zero.

PRINT/CHANNEL uses the one-character **Class** value as the formname and displays it on the Print Spool screen as the formname for the file. You can then use the formname as criteria for determining when to print the files or you can create a forms overlay file of the same name to load printer control data. Several other header options are available, so use this special feature only as a last resort.

Ignore n lines from start of file.

This option specifies the number of lines (**n**) to delete from the start of a file when the spool receives the file. A common application is to delete the first two records of a punch file because they contain a blank card and a file separator card. The maximum value is **32767** lines.

Strip spool header?


When you write files to disk, you can remove spool headers from the files. This option only displays when the destination is **SPOOL** or **(FILE)**. If you strip the spool header when the destination is **SPOOL**, the file has no header information and is assigned a class of **Z**. The most useful application is to set the option to **Yes** for **SPOOL1→(FILE)** so the print spool uses the header information to route the file via a spool printer (**SPOOL1**), but does not preserve the header in the final destination on disk.

No Default. Do not strip the spool header.

Yes Remove the spool header from the file.

4 Run Diagnostics

You can use the PRINT/CHANNEL self test to verify you correctly installed the adapter and CAB and that they function properly. You must use the adapter test plug and the CAB test plugs for the self test.



The adapter test plug comes strapped to the cable connecting the CHANNEL adapter and CAB.



The Diagnostic Tools Bag contains the CAB terminator plugs, loopback test plugs, and instructions for installing the plugs on the CAB.

You must run the self test in two phases:

- Phase 1 tests the adapter and cable.
- Phase 2 tests the CAB.

Note: Always perform Phase 1 before Phase 2. If you have a problem with the adapter in Phase 1, you can avoid disconnecting the CAB from the channel for Phase 2.

4.1 Phase 1: Adapter Installation and Settings

Phase 1 of the self test locates the adapter and sends a series of 256 character strings in a rotating pattern. The adapter test plug returns the data through the receive side of the adapter. Then the self test verifies that the returned data matches the sent data.

Follow these steps to run Phase 1:

1. Connect the adapter cable to the adapter. Then attach the test plug to the other end of the cable.
2. From the PRINT/CHANNEL Print Sessions screen, select **Adapter Description**
3. From the Adapter Description screen, set **Run diagnostics** to **Yes**.

The following screen displays:

```
CHANNEL Diagnostics

A test of the CHANNEL adapter, Channel Attach Box, and Channel Attach Box
cable will now be performed. This test will attempt to verify
that the adapter is correctly installed and that the Interrupt and
DMA request levels are functioning properly.

The test can be run with the Channel Attach Box connected to the channel or
with test plugs installed.

If a loopback test of the Channel Attach Box is desired, install the test
plugs at this time. If a loopback test of the adapter and
Channel Attach Box cable is desired, disconnect the cable from the Channel
Attach Box and connect that end to the proper test plug.

Press any character to begin the tests.

Any key
```

Follow the instructions on the screen for each test phase.

A screen similar to the following displays if the test runs successfully:

```
CHANNEL Diagnostics

BARR/CHANNEL adapter found at device address 280.
Adapter using IRQ11. IRQ test passed.
Adapter using DMA level 5. DMA transfer test passed.
TAG loopback test passed.
BUS loopback test passed.
Diagnostics passed.

Any key
```

Note: The **Adapter using DMA level** message does not apply to the CHANNEL-IN (BT) adapter.

A failure during this phase might indicate a problem with the CHANNEL adapter installation. The self test error message might direct you to the problem. You can also check the following:

- Is the adapter installed correctly? Make sure the adapter is firmly in the slot.
- Is the adapter making a clean connection? Try cleaning the adapter's gold-plated fingers with a pencil eraser.
- ISA only: Is there an IRQ conflict with another adapter? If so, follow the instructions in the *BARR/CHANNEL* manual to reset the IRQ.
- ISA only: Is the device address specified in the software the same as the jumper settings on the adapter or is there a conflict with another adapter in the machine? Follow the instructions in the *BARR/CHANNEL* manual to change the device address in the software.
- ISA only: Are the BBF files (CHANIN.BBF and CHANDIAG.BBF) located in the same directory as the Barr EXE file?


4.2 Phase 2: CAB Installation and Connections

In this phase, the self test verifies connections from the adapter to the CAB through the bus and tag lines. It sends a series of 256 character strings in a rotating pattern. The bus and tag test plugs receive transmitted signals back to the test program. The self test verifies that the returned data matches the sent data.

Follow these steps to run Phase 2:

1. If the CAB is online with the mainframe, remove it from service. You usually need to isolate the mainframe channel by turning off a channel switch or varying each channel device offline, but these procedures vary.

Note: Phase 2 proceeds only if the self test determines that the CAB is isolated from the channel.
2. Physically disconnect the bus and tag cables from the CAB. Then attach the terminator plugs and loopback test plugs as follows:
 - a. Insert the Bus Terminator and Tag Terminator plugs in the Bus Out and Tag Out plug receptacles.
 - b. Insert the Bus Loopback and Tag Loopback plugs in the Bus In and Tag In plug receptacles.



CAB with terminator and loopback test plugs installed.

3. Verify that the adapter is connected to the CAB. If you previously connected the adapter test plug to the adapter cable, you need to remove the adapter test plug and re-attach the cable to the CAB.
4. From the PRINT/CHANNEL Print Sessions screen, choose **Adapter Description**. From the Adapter Description screen, set **Run diagnostics** to **Yes**.

If you encounter an error during this phase, contact Barr Technical Support.

Notes:

Start PRINT/CHANNEL

After you install and configure PRINT/CHANNEL, you can start the software from the DOS prompt or from the Installation Description screen. After you start the software, the Communication Scope menu displays. See Appendix B for information about scope characters.

Note: Always try to exit the PRINT/CHANNEL software normally before you power off or reset the PC. If you cannot do this, disable or power off the CAB before you power off or reset the PC.

5.1 Start from the DOS Prompt

Start from the DOS prompt if you want to use the existing configuration.

Type the following command at the DOS prompt:

```
spool
```

5.2 Start from the Installation Description Menu

Start from the Installation Description menu if you want to change the software configuration before you start the software.

1. Type the following command at the DOS prompt:

```
spool i
```

2. When you finish configuring the software, select **Exit and Save Changes** from the Installation Description menu and save your settings.
3. Select **Begin communication at Operation screen** on the Exit Options screen to start the software.

Notes:

Banner Page Detection Example

On some host computers, JES2 generates job separators (also called Job Start Banner and Job End Banner) for every job printed. In this example, the host computer was configured to generate one Job Start Banner and one Job End Banner for each job, as shown in Figures A-1 and A-2.

```

          CCCCCCCCCC  CCCCCCCCCC  TTTTTTTTTTTT  EEEEEEEEEEEE  SSSSSSSSSS  TTTTTTTTTTTT
CCCCCCCCCCCC  CCCCCCCCCC  TTTTTTTTTTTT  EEEEEEEEEEEE  SSSSSSSSSS  TTTTTTTTTTTT
CC      CC  CC      CC      TT      EE      SS      SS      TT
CC      CC      TT      EE      SS      TT
CC      CC      TT      EEEEEEEE  SSSSSSSS  TT
CC      CC      TT      EEEEEEEE  SSSSSSSS  TT
CC      CC      TT      EE      SS      TT
CC      CC      TT      EE      SS      TT
CC      CC  CC      TT      EE      SS      SS      TT
CCCCCCCCCCCC  CCCCCCCCCC  TT      EEEEEEEEEEEE  SSSSSSSSSS  TT
CCCCCCCCCCCC  CCCCCCCCCC  TT      EEEEEEEEEEEE  SSSSSSSSSS  TT

JJJJJJJJJJ  000000000000  BBBBBBBBBB  3333333333  11      2222222222  444      11
JJJJJJJJJJ  000000000000  BBBBBBBBBB  333333333333  111      222222222222  4444      111
JJ      00      00  BB      BB  33      33  1111  22      22      44  44  1111
JJ      00      00  BB      BB  33      33  11      22      44  44  11
JJ      00      00  BB      BB  33      33  11      22      44  44  11
JJ      00      00  BBBBBBBBBB  3333  11      22      444444444444  11
JJ      00      00  BBBBBBBBBB  3333  11      22      444444444444  11
JJ      00      00  BB      BB  33      33  11      22      44  11
JJ      00      00  BB      BB  33      33  11      22      44  11
JJ      00      00  BB      BB  33      33  11      22      44  11
JJJJJJJJ  000000000000  BBBBBBBBBB  333333333333  1111111111  222222222222  44  1111111111
JJJJJJ  000000000000  BBBBBBBBBB  3333333333  1111111111  222222222222  44  1111111111

**START*****START*****START*****START*****START*****START*****START*****START***
*
* JOBID:          JOB31241
* JOB NAME:       CCTEST
* USER ID:       BARRGAT
* SYSOUT CLASS:   S
* OUTPUT GROUP:  2.1.1
* TITLE:
*
* DESTINATION:   R122
* NAME:          Staal
* ROOM:
* BUILDING:
* DEPARTMENT:
* ADDRESS:
*
*
*
* PRINT TIME:    14:26:01
* PRINT DATE:    22 JAN 1996
* PRINTER NAME:  R122.PR1
* SYSTEM:        NER1
*
**START*****START*****START*****START*****START*****START*****START*****START***

```

Figure A-1. Sample Job Start banner.

```

          CCCCCCCCCC CCCCCCCCCC TTTTTTTTTTTT EEEEEEEEEEEE SSSSSSSSSS TTTTTTTTTTTT
          CCCCCCCCCC CCCCCCCCCC TTTTTTTTTTTT EEEEEEEEEEEE SSSSSSSSSS TTTTTTTTTTTT
          CC      CC      CC      TT      EE      SS      SS      TT
          CC      CC      CC      TT      EE      SSS      TT
          CC      CC      TT      EE      SSSSSSSS      TT
          CC      CC      TT      EEEEEEEE      SSSSSSSS      TT
          CC      CC      TT      EEEEEEEE      SSSSSSSS      TT
          CC      CC      TT      EE      SSS      TT
          CC      CC      TT      EE      SS      SS      TT
          CCCCCCCCCC CCCCCCCCCC TT      EEEEEEEEEEEE SSSSSSSSSS      TT
          CCCCCCCCCC CCCCCCCCCC TT      EEEEEEEEEEEE SSSSSSSSSS      TT

JJJJJJJJJJ 000000000000 BBBB BBBB 3333333333 11 2222222222 444 11
JJJJJJJJJJ 000000000000 BBBB BBBB 3333333333 111 222222222222 4444 111
JJ 00 00 BB BB 33 33 1111 22 22 44 44 1111
JJ 00 00 BB BB 33 33 11 22 44 44 11
JJ 00 00 BBBB BBBB 3333 11 22 4444444444 11
JJ 00 00 BBBB BBBB 3333 11 22 4444444444 11
JJ 00 00 BB BB 33 11 22 44 11
JJ JJ 00 00 BB BB 33 11 22 44 11
JJ JJ 00 00 BB BB 33 33 11 22 44 11
JJJJJJJJJJ 000000000000 BBBB BBBB 333333333333 1111111111 222222222222 44 1111111111
JJJJJJJJ 000000000000 BBBB BBBB 3333333333 1111111111 222222222222 44 1111111111

**END*****END*****END*****END*****END*****END*****END*****END*****END*****
*
* JOBID: JOB31241 *
* JOB NAME: CCTEST *
* USER ID: BARRGAT *
* SYSOUT CLASS: S *
* OUTPUT GROUP: 2.1.1 *
* TITLE: *
*
* DESTINATION: R122 *
* NAME: Staal *
* ROOM: *
* BUILDING: *
* DEPARTMENT: *
* ADDRESS: *
*
*
* PRINT TIME: 14:26:06 *
* PRINT DATE: 22 JAN 1996 *
* PRINTER NAME: R122.PR1 *
* SYSTEM: NER1 *
*
**END*****END*****END*****END*****END*****END*****END*****END*****END*****

```

Figure A-2. Sample Job End banner.

The following portion of the sample banner page includes possible search data strings.

```

      1          18      25
      |          |      |
31-**START*****START*****START****
*
* JOBID:          JOB31241
34-* JOB NAME:    CCTEST
* USER ID:       BARRGAT
36-* SYSOUT CLASS: S
* OUTPUTGROUP:2.1.1
* TITLE:

```

The ****START**** string is a good search choice because it probably does not occur anywhere else in the data. It always shows up in column 1 of line 31 on this sample banner page. Similarly, the ****END**** string always appears on the sample Job End Banner.

The job name and class also print on the banner page so you can extract this information. The job name is three lines below and class is five lines below the ****START**** string. Both fields begin in column 18. The job name can extend as far as column 25.

Figures A-3 and Figure A-4 show you how you would enter this information on the PRINT/CHANNEL Printer Definition screen.

```

                                PRINT/CHANNEL Printer Definition

Printer Address:                0E
Enable or Disable device?      Enabled

.....
                                Banner Recognition Information

Remove banner pages after processing? No
Starting line: 31      Number of lines: 1
Header pages:  1      plus 0 additional page(s)
Trailer pages:  1      plus 0 additional page(s)

Text string 1 in column:  1
**START**

TRAILER  text string

Text string 2 in column:  1
**END**

                                Enter character

```

Figure A-3. Banner Recognition Information screen.

PRINT/CHANNEL Printer Definition

Printer Address: OE
 Enable or Disable device? Enabled

.....
 Print Job Parameter Extraction Information

(These parameters are extracted from the first page of
 the job. This will be the first banner page if present.)

Line numbers are relative and are measured BEFORE or
 AFTER the banner text matching line.

	Acquire	Line	Beg Col	End Col
Job name:	AFTER	3	18	25
Form name:	NO	0	0	0
FCB name:	NO	0	0	0
Copies:	NO	0	0	0
Priority:	NO	0	0	
Class:	AFTER	5	18	

Choice? + -

Figure A-4. Print Job Parameter Extraction Information screen.

Communication Scope and Console Messages

Communication Scope characters appear on the top line of your PRINT/CHANNEL Operation screen to tell you the mainframe is communicating with your Barr PC. The characters in Table B-1 might appear, where **NN** is the channel address.

Table B-1. Communication Scope Characters

Character	Color	Meaning
rNN	yellow	Device ready.
iNN	red	Intervention state. Indicates you have a flow-control problem because you are low on buffers or trying to write to a suspended device.
hNN	yellow	Header page recognized.
tNN	yellow	Trailer page recognized.
eNN	yellow	End of print job.
p	white	Channel 1 Skip received.
d	white	Total of 256 lines received without Channel 1 Skip.

The **rNN** message should display first to indicate the device is ready to receive print jobs.

The following messages display in the console portion (the blue area) of the Operation screen to help you diagnose problems.

Ready

The device is ready at software startup or the device has left the intervention state.

Time out forced E0J

Your job ended because the device timed out.

**BARR/CHANNEL Driver is incompatible with BBF file.
Driver firmware version level:4**

Your software version does not match the BBF file in your Barr software directory.

BARR/CHANNEL incompatible with BBF file.

You are trying to use a BBF file from another Barr software option. You need new software or a new BBF file. Call Barr Technical Support.

BARR/CHANNEL unable to open BBF file.

You either do not have a BBF file or it is not in the directory with the Barr software's EXE file.

BARR/CHANNEL error encountered while loading BBF file.

The Barr software was unable to initialize the adapter because of a problem with the adapter or with your particular PC.

BARR/CHANNEL initialization error. Code:

Your software would not initialize. Call Barr Technical Support with the code number.



Warranty

Software License Agreement: Single-User

Barr Systems, Inc. (“Barr Systems”) grants and Licensee accepts the terms and conditions of this agreement which provide a non-transferable and non-exclusive license to use the software program (“Licensed Software”) enclosed herewith on one single-user workstation, so long as Licensee complies with the terms of this agreement. Licensee’s rights hereunder are those of a licensed user only and the Licensed Software shall at all times remain the property of Barr Systems.

Licensee agrees to pay for licenses for additional user copies of the Licensed Software if Licensee intends to, or does, use it on more than one single-user workstation at a time.

Acceptance

Licensee understands that the use of the Licensed Software, or the use of any of the computer hardware (the “Product Hardware”) purchased from Barr Systems, constitutes acceptance of the terms and conditions of this Software License Agreement and this Limited Warranty with respect to the Product Hardware and the Licensed Software.

Maintenance and Limited Warranty

The Licensed Software and the Product Hardware are under warranty for a period of one year following the date the Licensed Software and the Product Hardware were mailed or otherwise made available to Licensee. Support for the Licensed Software Product Hardware beyond the initial one-year warranty period may be obtained by Licensee through the purchase of an annual Licensed Software and Product Hardware Maintenance Agreement from Barr Systems.

Barr Systems warrants that the Licensed Software and the Product Hardware will perform substantially in accordance with the published specification statement, documentation, and authorized advertising. Provided Barr Systems is notified of significant errors during the warranty period, Barr Systems shall, at its option:

- (1) Provide telephone support (phone 800-BARR-SYS or 352-491-3100) to correct significant and demonstrable Licensed Software program or documentation errors within a reasonable period of time, or
- (2) Repair or replace the Product Hardware within a reasonable period of time if it should prove defective, or
- (3) Provide or authorize a refund of the purchase price of the Licensed Software or the Product Hardware.

Transfer or Reproduction

The Licensee shall not sell, assign, sublicense, copy, or otherwise reproduce in whole or in part, or transfer any copies of the Licensed Software to another person, subsidiary, parent company, or other company without the express written permission of Barr Systems. Barr Systems has the legal right to trace serial numbers and to take legal action if these conditions are violated.

Limited Warranty

THE LICENSED SOFTWARE AND THE PRODUCT HARDWARE ARE PROVIDED "AS IS." ALL WARRANTIES AND REPRESENTATIONS OF ANY KIND WITH REGARD TO THE LICENSED SOFTWARE AND THE PRODUCT HARDWARE ARE HEREBY DISCLAIMED, INCLUDING IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, EXCEPT THAT BARR SYSTEMS WARRANTS THAT THE LICENSED SOFTWARE AND THE PRODUCT HARDWARE, WHEN DELIVERED, WILL OPERATE SUBSTANTIALLY AS DESCRIBED IN THE USER

DOCUMENTATION OR GUIDE. UNDER NO CIRCUMSTANCES WILL BARR SYSTEMS BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL, SPECIAL OR EXEMPLARY DAMAGES, EVEN IF APPRISED OF THE LIKELIHOOD OF SUCH DAMAGES OCCURRING. LICENSEE'S SOLE AND EXCLUSIVE REMEDY FOR THE BREACH OF ANY PROVISIONS OF THIS AGREEMENT OR FOR BREACH OF WARRANTY SHALL BE LIMITED TO THE REPAIR OR REPLACEMENT OF THE LICENSED SOFTWARE OR THE PRODUCT HARDWARE BY BARR SYSTEMS, OR THE REFUND OF THE PURCHASE PRICE. THE CHOICE OF REMEDIES SHALL BE MADE AT THE OPTION OF BARR SYSTEMS.

Licensee and Barr Systems agree that the Licensed Software and the Product Hardware are not intended for use by Licensee as “consumer goods” under state or federal law.

This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state. Some states do not allow limitations on how long an implied warranty lasts or exclusion or limitation of incidental or consequential damages; therefore, the limitations set forth in this agreement may not apply to you.

Copyright

The Licensed Software is the sole and exclusive property of Barr Systems, which is licensed and distributed by Barr Systems pursuant to a nonexclusive software license agreement; it is an unpublished work, with all rights reserved, and contains confidential information and trade secrets proprietary to Barr Systems. Disassembly or decompilation is prohibited; patents pending.

Licensee acknowledges and agrees that the Licensed Software is copyrighted and that Licensee is not authorized to reproduce any copies of the Licensed Software, nor allow others to reproduce any copies except in accordance with instructions in this manual.

Licensee further agrees that Licensee does not have, and shall not gain, any exclusive copyright rights with regard to the Licensed Software.

Miscellaneous

These definitions shall govern the use of terms in this agreement: "Barr Systems, Inc.," a Florida corporation, whose address is 4500 NW 27 Avenue, Gainesville, Florida 32606-7031, is the author and owner of the Licensed Software; "Single-user workstation" is defined to include any device from which the enclosed Licensed Software may be used or accessed; "Multiple user" is defined as more than one single-user workstation. Where networks of terminals are used, each such terminal shall be counted as a separate single-user workstation and must be licensed individually; "Licensed Software" is the computer program licensed to Licensee, regardless of the form in which Licensee may subsequently use it, and regardless of any modification which Licensee may make to it. The Licensed Software is distributed in machine-readable form only and no source code is provided; "License" means this agreement and the rights and obligations which it creates under the United States Copyright law and the laws of the several states and territories of the United States; "Licensee" refers to the end user (individual or company); "Product Hardware" refers to any computer hardware manufactured, sold, or distributed by Barr Systems.

This is the entire agreement between Barr Systems and Licensee and it cannot and shall not be modified by purchase orders, advertising, or other representations by anyone.

All notices or other communications given under this agreement shall be in writing, sent to the address presented above as the principal place of business of Barr Systems, or such other addresses as Barr Systems may designate in writing.

Both parties acknowledge that they have read all the terms of this agreement, understand it and are authorized to enter into it and agree to be bound by its terms and that it is the complete and exclusive statement of the agreement between the parties, which supersedes all proposals, oral or written.

If any provision, or portion thereof, of this agreement shall be deemed invalid and/or inoperative, under any applicable statute or rule of law, it is to that extent to be deemed omitted and shall have no effect on any other provisions of the agreement.

This agreement shall be construed and enforced in accordance with the laws of the State of Florida and is deemed entered into at Alachua County, Florida, by both parties.

Notes:



Glossary

adapter

Add-on equipment you can plug into a PC to allow the PC to connect to another device.

BBF

Files used to control data flow in and out of the channel or to perform diagnostics. These files are loaded into programmable chips on the adapter.

buffer

An area of computer memory used to perform input or output operations. The software reads data into a buffer or writes data from a buffer.

bus and tag cables

Cables used to connect devices to mainframe channels. The bus cable transmits data and the tag cable controls information on the bus.

CAB

Channel Attach Box. Allows you to electronically isolate the PC from the mainframe channel and other devices on the channel.

channel attached

Direct way to attach printers to S/390 mainframes.

communications protocol

A specification of data and control message formats and their meanings. Both the sender and receiver in a communication link must follow this specification.

data streaming

The uninterrupted transfer of information over an interface to achieve high data transfer rates.

diagnostics

A program to detect and isolate errors in programs and faults in equipment.

DMA

Direct Memory Access.

EOJ

End Of Job.

FCB

Forms Control Buffer. A record sent from a host to a remote to specify vertical forms control.

host computer

A computer that controls the communications network, stores databases, and has a large computing and memory capacity. Other computers can connect to the host to share its resources.

IRQ

Interrupt Request. A request for processing on a particular priority level.

LED

Light-Emitting Diode.

mainframe

A large central computer that offers a full set of computing services. The term originated when the central processor, memory, and input/output channels were located in one central housing called the mainframe. Synonymous with host computer.

network

An arrangement of nodes and connecting branches for information interchange.

parity

A bit appended to a group of binary digits to ensure that the sum of bits is either even or odd. Parity serves as an error-detection scheme for data communications.

print queue

A list of items waiting to print.

print spooling

A way to manage printing files on one or more printers.

protocol

See communications protocol.

PVC

Permanent Virtual Circuit.

spooling

Simultaneous Peripheral Operations Online. Spooling allows several independent flows of data to proceed concurrently. For example, files can be sent from disk to the host computer while other files are printed. See print spooling.

terminator plug

A part that ends the cable path on a computer system. The terminating plug is attached to the last device in a series.

UCS

Universal Character Set. A printer feature that permits you to use various character arrays.

UNIX

An operating system for workstations developed by Bell Laboratories that features multiprogramming in a multiuser environment. It was originally developed for minicomputers but can now be used on mainframes and microcomputers.

V AC

Volts Alternating Current.

VAX

A super-minicomputer made by Digital Equipment Corporation.

Index

#

3211 channel printers 1, 5
3211 protocol 3

A

Acquire 16, 41
Adapter 5, 6, 19, 44
 connection to CAB 61
 definition 17, 42
 description 61
 diagnostics 57, 58, 59
 errors 59
 installation 59
 ISA 59
 test plug 57, 58
Adapter using DMA level message 59
Address 10, 35
AFTER 16, 41
AND test string 2 14, 40
AS/400 1, 5
ASCII 23, 48
ASCII data with ASA carriage control
 27, 52
Assign Devices 20, 45

B

Banner pages 65–68
 END string 67
 START string 67
Banner recognition 3, 67
BARR/CHANNEL adapter 6
BARR/PRINT for LAT 5
BARR/PRINT for TCP/IP 5
BARR/SPOOL 1–2, 5, 21, 46
BBF files 59
BEFORE 16, 41
Beg Col 16, 41

Binary 24, 49
BIOS 43

C

CAB 3, 5, 57
 connection to adapter 60
Carriage control, normal 26, 51
Class 4, 16, 30, 41, 55
Communication Scope 63, 69
Configure software 63
Copies 4, 16, 41

D

Data streaming 43
DC Interlock 18, 43
DCI 18, 43
DE 10, 36
Destination devices 21, 46
Device Address 18, 43
Device end 10, 36
Diagnostics 19, 44
DMA request 18, 43
DOS 5
DOS prompt 63

E

Enable or Disable device 10, 35
End Col 16, 41
END string 67
Enforce UCS Size 11, 36
EOF timeout in seconds 10, 35
Error messages 59

F

FCB 4, 12, 37, 38
 detection 3

name 4, 16, 41
First printer address 8
Fixed length 24, 49
Form name 4, 16, 41

H

Header pages 14, 39
High Speed Transfer 18, 43
HST 18, 43

I

Ignore n lines from start of file 30, 55
IGNORE text string 2 14, 40
Interrupt request 18, 43
Intervention Required 11, 36
Intervention timeout in seconds
 10, 36
IRQ 18
ISA adapter 7

J

Job End Banner 65, 66
Job name 16, 41
Job separation 3
Job separation by banner page
 recognition 12, 37
Job Start Banner 65

L

LAN 1
Line 16, 41
Loopback 60

M

Mainframe print sessions 8, 34
Memory 5

N

N ASCII lines 23, 48
Number of lines 14, 39

O

Operation screen 69
Options 26, 52
OR text string 2 14, 15, 40
OUTPUT statement used in file
 27, 52

P

Parameter extraction 68
PCI adapter 33
Plus 0 additional page(s) 14, 39
PostScript 25, 50
Power off 7, 33
PRINT/TWINAX 5
PRINT370 1–2
Printer
 address 10, 35
 definition 9, 35
Printers 1–2, 4
Priority 4, 16, 41

R

Receive mode 26, 51
 ASCII 22, 26, 30, 47, 51, 55
 binary 24, 49
 fixed length 24, 49
 N ASCII lines
 22, 23, 26, 47, 48, 51
 PostScript 25, 50
 S/370 channel
 24, 26, 30, 49, 51, 55
 transparent 24, 49
 variable ASCII lines
 22, 23, 26, 47, 48, 51
Remove banner pages after processing
 13, 39
Reset 7, 33
Run diagnostics 19, 44, 61

S

S/390 Channel 24, 26, 49, 51
Self test 57, 58
 bus 60

- error message 59
- tag 60
- Software version number iii
- Source devices 21, 46
- Spool 21, 46
- Spool header from data 29, 54
- Spool printer 21, 46
- START string 67
- Starting line 14, 39
- Startup 7, 33, 63
- Strip spool header 31, 56
- Subchannel address 10, 35
- Suspend EOF timeout after FCB
 - 12, 37

T

- Terminator 60
- Test plugs
 - adapter 57
 - CAB 57
- Text string 1 in column 14, 39
- Text string 2 in column 15, 40
- Timeout 3, 4
- Trailer pages 14, 39
- TRAILER text string 2 14, 15, 40
- Transfer mode 18, 43
- Transparent 24, 49

U

- UCS 11, 36
- UCS size 11, 37
- UNIX 1, 5

V

- Variable ASCII lines 23, 48
- VAX 1, 5
- Version number iii

Notes: